

---

**IMPROVE YOUR  
GOLF  
AT HOME**

- HIT A REAL GOLF BALL
  - ONLY 40 FT. OF SPACE NEEDED
  - COMPLETELY SAFE BALL WILL NOT HIT THE PLAYER
  - INDICATES HOOK OR SLICE
- 


**HOUSE OF ZOG**

803 N. ALFRED ST.  
Los Angeles 90069, Calif.



### **The "Golfing Gizmo"**


*The "Golfing Gizmo" enables you to improve your golf at home, without the costly expense of a driving range, or the waste of time chasing practice shots at your golf club. Many golfers prefer to practice their shots without any onlookers; the "Golfing Gizmo" lets you practice your shots in the privacy of your own home, at your own convenience.*



**1.** Use your yard, parkway, or any area that allows 40 feet of space. Insert stakes each end of elastic, stretch 25 inches. Place in turf flush with ground. Place ball at right angles to elastic, full length of cord. Tee the golf ball in your usual manner.



**2.** Drive golf ball with full power, with iron or wood clubs. You are hitting a real golf ball, not a toy or plaything. Concentrate on your own improvement in coordination, rhythm, and power. "Golfing Gizmo" gives you more practice, in less time, at less cost.



**3.** When hit correctly, ball returns near tee, indicating 175-yard drive. If ball returns to your left, it shows slice; if ball returns to your right, it shows hook. If ball is topped, it will not return, must be retrieved. Regular practice will improve your game.

### PARTS LIST FOR "GOLFING GIZMO"

---

Part #B-101—Golf Ball with Nylon Loop . . . .	\$2.50
Part #C-102—21 foot Cotton Cord, prepared for attaching to Elastic Cord, and to Ball Loop . . . . .	.35
Part #N-103—21 foot Nylon Cord, prepared for attaching to Elastic Cord, and to Ball Loop . . . . .	.70
Part #E-104—Elastic Cord with Loops . . . . .	.60

---

The above prices include Parcel Post and Shipping Charges

Send Cash, Check or Money Order with order to—

**HOUSE OF ZOO**  
 803 N. ALFRED ST.  
 Los Angeles 90069, Calif.